

# **USER MANUAL**

# **TORQUE TESTER**

FSB Series

File: 2016-05-21 FSB-141 FSB017 GB

## Contents:

1.	Introdu	Introduction3			
2.	Basic S	Set	3		
З.	Safety	instructions	4		
3.1	Main safety rules				
3.2	Safety	rules	5		
3.2	2.1	Transport safety rules	5		
3.2	2.2	Safety rules during start-up and operation	5		
3.2	2.3	Safety rules during conservation	6		
4. 5	Fast st Force	an meter general view	7		
6.	Techni	cal data	0		
7.	Keys a	nd indicators	10		
8.	Prepar	ing the force gauge for operation	11		
9.	Turnin	g on the force gauge	12		
10.	Accum	ulators exchange	13		
11.	Descri	otion of measurement methods	14		
11.1	Measu	ring actual and peak value of a pressure/pull force	14		
11.Z 12	Conne	characteristics measurement, measurement registration to memory	15		
12.	User's	Menu	10 17		
13.1	Measu	rement	17		
13	3.1.1	Measurement speed	18		
13	3.1.2	Units	18		
13	3.1.3	Auto-zeroing	20		
13	3.1.4	Comparison with threshold values MIN / OK / MAX	21		
13.2	Memory		22		
13	3.2.1	Gathering results	23		
13	3.2.2	Presentation of collected measurements (Statistics)	24		
13	3.2.3	Save, read, erase memory (Statistics)	24		
13.3	Config	uration	26		
13	3.3.1	Setting serial ports	27		
13	3.3.2	Force meter calibration	28		
13	3.3.3	Information	29		
13	3.3.4	Setting date and time	30		
13	3.3.5	LCD settings	31		
13	3.3.6	Selecting the menu language	32		
13	3.3.7	Printout settings	33		
13	3.3.8	Turning the sound ON/OFF when using the keypad (beep)	34		
13	3.3.9	Automatic power OFF (Auto-OFF)	34		
13	3.3.10	Monitoring the batteries' charge level (Battery)	35		
13	3.3.11	External input	37		
13	3.3.12	Firmware update	37		
13	3.3.13	Defaults	38		
14.	Mainte	nance, troubleshooting and repairing minor types of damage	39		
15.	FSB menu diagram40				

## 1. Introduction

The FSB series torque testers produced by AXIS Sp. z o.o. are designed for dynamic measuring of torque in manufacturing and quality control applications.

Measurements results can be presented as graph or histogram and saved on microSD cards.

The RS232C and USB interface allows the measurement results to be transmitted to a computer or a printer for further analysis or recording.

## 2. Basic Set

The basic set includes the following elements:

- 1. Force gauge (meter + sensor),
- 2. Handgrip 2 pieces,
- 3. Accumulators NiMH 2700mAh 4 pcs.
- 4. Power supply unit ~230 V 50 Hz / = 12 V; 1.25 A,
- 5. Case
- 6. Force gauge-computer cable
- 7. CD containing an operation manual and software,
- 8. Warranty.

## 3.1 Main safety rules



Read carefully the safety instructions included below. Observe these instructions to avoid electrocution or damage to the force gauge itself or other devices connected to the force gauge.

- Repairs and any necessary adjustments may only be conducted by qualified personnel.
- Do not use the force gauge when any part of the enclosure has been removed.
- Do not use the force gauge in potentially explosive atmospheres.
- Do not use the force gauge in areas with a high humidity.
- In the case of suspected damage to the force gauge, turn off the gauge and do not use it until it is examined by a specialised servicing facility.

## 3.2 Safety rules

## 3.2.1 Transport safety rules

Force meter and included equipment should be transported from producer to receiver in original company box.

To transport force meter during exploitation original producer case should be used.

## 3.2.2 Safety rules during start-up and operation

Force meter with equipment supplied by producer is a safe device, what was achieved by application of fire protection and elimination of mechanical, chemical, explosive etc threads.

In order to avoid danger we suggest to:

Lp.	Recommendation	Warnings
1	Avoid contact with flood, water or other liquids due to high voltage 230V.	
2	Damaged accumulators handle with care. Use rubber gloves and safety glasses if necessary.	
3	The proper disposal of used force meter.	
4	User manual training.	??
5	Periodic monitoring of connections	Next control date:

Specific recommendation:



Risk of electric shock due to the use of  $\sim 230V 50Hz$  voltage via external feeder. It is unacceptable to spill the feeder or use it when the enclosure is damaged cause it may cause electric shock.



In order to avoid leakage of electrolyte from accumulators immediate disposal of used accumulators from force meter is suggested.

### 3.2.3 Safety rules during conservation

Force meter doesn't need conservation except accumulators exchange when used – that happens when after full recharge the force meter working time is shorter more than 20% from the value suggested by producer.



If the device seems to be damaged immediately stop operation.

## 4. Fast start

Prepare force meter to work by selecting proper measuring tip (force gauge with internal sensor) or after mounting proper working post (force gauge with external sensor).

Turn on force meter by using *ON/OFF* key and leave the device in stationary position. That will enable zeroing, software version displaying and zero indication. Force meter is ready to work after following screen displays:







The force measurement is continuous. Display continuously indicates actual force value measured by meter. Force direction is signalized by an arrow in lower part of screen and a sign + (pressing force) or - (pulling force). Saving actual force indication to memory is done by pressing *MEM* key.

Changing actual torque value indication into peak value measurement done by pressing *PEAK* key. is Indication stabilization sign changes into LOCK sign and force meter changes mode into peak value in one directions. Pressing again PEAK key changes peak torque direction: first for pressure force  $(PK \uparrow)$  and after another *PEAK* pressing for pulling (PK√). zeroing is done by  $\rightarrow 0 \leftarrow \text{key}$ .

## Attention:

Dynamical forces measurement should be carried out by saving to memory series of measurements with given sample time, then display force characteristics and statistical results (rozdz. 14.3 *Memory*).

## 5. Force meter general view

FSB force meter:



## 6. Technical data

Туре	FSB2	FSB5	FSB10	
Maximum force measured	2Nm	5Nm	10Nm	
Reading graduation (d)	0,001Nm	0,002Nm	0,01Nm	
Accuracy	±0,5% F.S.			
Measurement units	Nm, N*cm, kgf*m, gf*m, lbf*in			
Operating temperature		-10 ÷ 40°C		
Internal resolution		24 bits (16mln graduation)		
Process speed	Regi	ulated max 1000 measurement	s/s	
Internal memory capacity		1x6400 measurements		
Interface	RS-232C and USB, options: Bluetooth, WE trigger gate, WY transoptor			
	MicroSD card slot: compa	atibility with SDSC (standard) c	ards and SDHC class 4	
Assisting software	FM (time characteristics, statistic analysis,			
	data archiving )			
Display	LCD graphical			
Measurement ontions	Maximal value measurement, serial measurement,			
	dynamic measurement (time diagrams)			
Power supply	Ni-Mh batteries set 2700mAh			
	+ supply ~230V 50Hz / 12V 1,2A			
Accumulator working time	~20h (~45h backlighting off)			
Dimensions	215x100x40mm (meter)			
Weight		430g (without batteries)		

# 7. Keys and indicators

ON/OFF UNIT/CLEAR BACKLIGHT	<ul> <li>Main keys:</li> <li>ON / OFF key (standby),</li> <li>Change units / cancel selection or change a parameter value,</li> <li>Press and hold – move to measurement menu (Statistics/Reset)/return</li> <li>Turn on illumination (ECO mode),</li> </ul> Navigation keys: <ul> <li>Move cursor up or increase the digit marked by</li> </ul>	MAXIS <sup>®</sup> ON/OFF UNIT/CLEAR BACKLIGHT BACKLIGHT → PEAK → 0← ENTER PRINT
$\checkmark$	<ul><li>the cursor,</li><li>Move cursor down or decrease the digit marked by the cursor,</li></ul>	MENU
$\rightarrow$	<ul> <li>Move to the next menu level or display the next option,</li> <li>Move to the previous menu level or display the</li> </ul>	
$\leftarrow$	previous option,	
ENTER	- Confirm the entered parameter or select a highlighted option.	
MENU PEAK MEM PRINT →0←	<ul> <li>Function Keys:</li> <li>Meter function menu (diagram menu - chapter 18)</li> <li>Measure the maximum value,</li> <li>Save the result to the memory, press and hold – sav</li> <li>Print result (transmission via RS-232C connector).</li> <li>Force meter indications zeroing</li> </ul>	, /e to memory menu,
MIN/OK/MAX MAN/ACQ	<i>Status indicators:</i> - Indications below MIN; in range MIN÷MAX; abov - Manual/automatic measurements mode	e MAX
►	<ul><li>Indicates that the weighing result has stabilised,</li><li>Direction of measured force,</li></ul>	
SLW/FST AUT SD	<ul> <li>Slow/fast measurement mode,</li> <li>Autozeroing on</li> <li>microSD card mounted</li> </ul>	

#### Note:

Numbers are entered using the navigation keys. First, the cursor is placed in the right digit position.

## 8. Preparing the force gauge for operation



If the force gauge has been transported from an area with low temperature to an area with a higher temperature, e.g. during winter, water may condensate on the gauge's enclosure. In such a case, do not turn on the gauge's power supply, as it may lead to damage to the gauge or improper operation. Before turning on the gauge, leave it for 1 hour to acclimatise.

## 9. Turning on the force gauge

# AXIS

AXIS Sp. z o.o. ul. Kartuska 375B 80-125 Gdańsk

ZEROING	
ESB000	

Туре		
	MAN	SLW AUT 0.000N·m
		□>     +

Place the gauge in the operating position, e.g. horizontal position (by laying it on a table). Turn on the gauge by pressing the *ON/OFF* key.

When necessary, plug the gauge's power supply unit to a  $\sim 230 \text{ V}/50 \text{ Hz}$  socket and connect the power supply unit's plug to the gauge's 12 V socket.

The gauge automatically tests the electronic subassemblies and then resets. During this operation, the gauge should remain stationary and its sensor should not be affected by any forces.

After the resetting has been successfully completed, the gauge indicates zero.

Unsuccessful resetting is signalled by an appropriate message.

#### Note:

It is possible to accelerate the resetting process by pressing the *MENU* key, which will recall the results from the previous resetting.

If the batteries are low, leave the gauge's external power supply unit ON until they are fully recharged. The batteries' charge level is signalled by an indicator in the upper section of the display.

## 10. Accumulators exchange

If during exploitation time working time of fully charged accumulators shortens to 20% of the nominal value (under 4h), replace them with new ones.

In order to exchange accumulators open the cover by tilting bracket and put new ones as indicated at the bottom of the housing (correct polarization).



## 11. Description of measurement methods

## 11.1 Measuring actual and peak value of a pressure/pull force

The zeroing process starts automatically after turning on the gauge or by pressing the  $\rightarrow 0 \leftarrow$  key.



Тур						<b>•••</b>
	MAN	$PK \rightarrow$	LOCK	SLW	AUT	
					0 10	N·m
					0.10	
-						+
-					MAX	+

To perform the measurement, indicate the force direction using an arrow in the display's lower bar section and "+" or "-"symbol.

To change the measurement from the value (continuous actual measurement) to the maximum value (peak measurement), use the PEAK key – stabilization indicator is replaced LOCK indicator. by Pressing again PEAK button will change direction of the measured force ( $PK \rightarrow$ ,  $PK \leftarrow$ ), zeroing by using  $\rightarrow 0 \leftarrow \text{key}.$ 

When measuring maximum value, at the bottom of the screen appears a bar showing actual force value and maximum force value for other force direction if it was measured before otherwise 0,00 value will indicate.

# 11.2 Force characteristics measurement, measurement registration to memory

In order to enable changing force measurement and to create results visualizations (graphs or histograms), force gauge is equipped with actual results buffer memory (RAM), EEPROM memory and microSD card (option). Detailed description of available options can be found in 14 chapter.



## 12. Connecting external devices

The force gauge is equipped with a socket for an external power supply unit, RS232C interface (RJ joint), USB interface and optional THR (thresholds) output.



Installation manual and drivers can be found on CD disc supplied together with force meter.

Joint ampacity OUTPUT: I  $_{max}$ =25mA / U  $_{nom}$ =24V (open collector type, emitters connected– GND).

IN voltage range WE(+)/WE(-): U in=12-18V / I in max=50mA

# Description of the data transmission (USB, RS232) protocol when working with a computer *(LonG)*:

The force gauge transmit the result as follows (8 bits, 1 stop, no parity, 4800 bps): Computer $\rightarrow$ Gauge: initiating signal S I CR LF (53 h 49 h 0Dh 0 Ah), Gauge $\rightarrow$ Computer: gauge indication according to the following format (16 bytes):

Description of individual bytes:

byte	1	- "-" or space
byte	2	- space
byte	3÷4	- digit or space
byte	5÷9	- digit, comma or space
byte	10	- digit
byte	11	- space
byte	12	- k, l, c, p or space
byte	13	- g, b, t, c or %
byte	14	- space
byte	15	- CR
byte	16	- LF

## 13. User's Menu

The User's Menu includes all functions and options necessary to operate the gauge or extend its functionalities.

USER MENU

- 1. Measurement
- 2. Memory
- 3. Configuration
- 4. Exit

To use the options of the USER's MENU, use the *MENU* key. Move the cursor to the desired option and press *ENTER*.

The menu includes:

- 1. Measurement measurement settings,
- 2. Memory data readout and saving options,
- 3. Configuration calibration and other options,
- 4. *Exit*.

## 13.1 Measurement

This selection includes the following functions to effectively assist you with the measurement:

- measurement speed in automatic mode,
- measurement unit choice,
- automatic zeroing,
- comparison with two threshold values (MIN / MAX),
- measured force direction change (accepted as plus + )

- 1. Measurement
- 2. Memory
- 3. Configuration
- 4. Exit

#### MEASUREMENT

- 1. Speed
- 2. Unit
- 3. Auto-zeroing
- 4. Threshold
- 5. Direction
- 6. Exit

Move the cursor to *Measurement* and press *ENTER*.

Move the cursor to the desired application and press *ENTER*.

## 13.1.1 Measurement speed

To obtain clear measurement results, it is recommended to adjust the speed of measurement to the dynamic properties of the measured object.

USER MENU 1. Measurement 2. Memory 3. Configuration	
MEASUREMENT	
1. Speed 2. Unit 3. Auto-zeroing 4. Threshold 5. Direction 6. Exit	
SPEED	]
1. Smp.time: 0.001 s 2. Exit	

Choose *Smp.time* and press *ENTER* to change sample time value using navigation keys.

## 13.1.2 Units

Torque units:

- newton-metre  $(N \cdot m)$  torque basic unit,
- newton-centimetre (N·cm):  $1N \cdot m = 100 \text{ N} \cdot \text{cm}$ ,
- kilogram-metre (kg·fm):  $1N \cdot m = 0,1020 \text{ kgf} \cdot m$ ,
- gram-force-metre (gf·m) :  $1N \cdot m = 1020$  gf·m,
- pound-force-inch (lbf·in): 1N·m= 8.85 lbf·in.

To change the units, press the UNIT/CLEAR or MENU key several times.



During mass measurement the force meter measures gravitation force and converts it to mass. Calculating force and mass unit is depended to gravitation force of the place of measurement. Default value is the producer gravitation value  $g = 9,81415 \text{m/s}^2$ . During very precise mass measurements (±0,1% of range) it is crucial to inscribe proper gravitation value of the measurement place (*Calibration* options).

#### 13.1.3 Auto-zeroing

When activated, this option automatically maintains zero indications on the gauge, if the gauge's sensor is not affected by any external force or if the zero indication was produced by pressing the  $\rightarrow 0 \leftarrow$  key. The range of values (calculated in the gauge's reading graduation near zero) subject to the reset must be entered under the *Range* option (2 digits).

USER MENU		
1.Measurement 2.Memory 3.Configuration 4.Exit		Use the na ENTER to so of the follow - ON – auto-2
1. Speed 2. Unit 3. Auto-zeroing 4. Threshold 5. Direction 6. Exit		- OFF – auto- Next, select $\rightarrow$ , $\leftarrow$ and auto-reset graduation).
AUTO-ZEROING 1. Status 2. Range 3. Art.zero 3. Exit	<on> 2 d <off><set></set></off></on>	Additional enables to see the value entering the A
	↑ ↓ ENTER	
AUTO-ZEROING		
1. Status 2. Range 3. Art.zero 4. Exit	< <u>ON&gt;</u> <off> 2 d</off>	

ENTER

 $\rightarrow$ 

←

Use the navigation keys and *ENTER* to select *Status* and one of the following options:

- ON auto-zeroing ON,
- OFF auto-zeroing OFF.

Next, select *Range* and use  $\uparrow$ ,  $\downarrow$ ,  $\rightarrow$ ,  $\leftarrow$  and *ENTER* to enter the auto-reset range (in reading graduation).

Additional option *Art.zero* enables to set device start zero to the value indicated before entering the *MENU*.

### 13.1.4 Comparison with threshold values MIN / OK / MAX

This selection includes the following functions to effectively assist you with the measurement:

- memory operations and data analysis,
- comparison with two threshold values (MIN / MAX).



the gauge's display.

## 13.2 Memory

During measurements in automatic mode results are saved in volatile memory (RAM – erasing data after supply off). Saving, readout, erasing data (single series of measurements) in EEPROM and reseting volatile memory (RAM) is done by options in lower part of *Statistics* function screen. It is possible to view results on force meter (chart, histogram, table).

Using microSD card enables to save and later readout of many series of measurements in chosen file. It is possible to write custom names (inscribed by user) of folders and files.

MicroSD memory card can be put out from force meter in order to edit files on computer (.txt) and import them to other specialized software. In order to do that use microSD/SD adapter and readout files on computer.

Put microSD card into force meter using pushing element. The card plunges completely into housing and locks. SD or SDH (SDHC) icon appears on display. Push the card in order to unlock it.



*Memory* option enables to:

- select gathering results mode,
- exposure of gathered measurements, storing , readout, deleting memory (Statistics),
- exit.

#### 13.2.1 Gathering results

USER MENU 1.Measurement 2.Memory 3.Configuration 4.Exit	Move the cursor to <i>Memory</i> and press <i>ENTER</i> .
MEMORY 1. Statistics 2. Settings 3. Exit	Move the cursor to <i>Settings</i> and press <i>ENTER</i> . Setting the mode for collecting data: - <i>MANUAL</i> – each time after <i>MEM</i> is pressed,
SETTINGS 1. Mode 2. Quantity 3. Smp.time 4. Record 5. Autosave 6. SD card 7. Exit	<ul> <li>- AUTO – automatically at specified intervals. Insert quantity of samples (max 100)</li> <li>After choosing Manual mode user should specify whether he wants to save the time of each measurement (<i>R/D&amp;T</i> option). In Autosave option user can choose the place of autosaving results (<i>EEPROM</i> or <i>SDCARD</i>). After selecting AUTO, enter the number of samples (max 100) and sampling time (0.1÷99.9 s. or 0,025÷25s depending on speed of measurement in Configuration).</li> </ul>

To start the collection of measurements, exit the menu and press *MEM* several times or press *MEM* for automatic save. When in the automatic save mode, press and hold *MEM* to go to the data save menu

#### 13.2.2 Presentation of collected measurements (Statistics)

The *Statistics* option allows for the following forms of presentation of the collected data:

<*PRINT>* – transmission to a printer, <*HISTOGRAM>* – bar graph, <*GRAPH>* – graph with a time axis.



To move the arrow (scroll the graph), use the  $\leftarrow$  and  $\rightarrow$  keys.

MIN

↑

MAX <L01 = 8>

#### 13.2.3 Save, read, erase memory (Statistics)

The Statistics option allows for the following:

- < SAVE > saves the data currently presented,
- < READ > reads a file from the memory,
- < RESET > erases the data currently presented,

< DELETE> – delete selected data file.

These options show up in the bottom bar (change option using  $\leftarrow$  or  $\rightarrow$  keys).

USER MENU 1.Measurement 2.Memory 3.Configuration 4.Exit	In order to choose saving location move the cursor to <i>Memory</i> and press <i>ENTER</i> .
MEMORY  1. Statistics 2. Settings 3. Exit SETTINGS	Move the cursor to Settings and press ENTER. Choose Mode. In Auto mode results are saved to RAM memory. In Manual mode saving to RAM, EEPROM or microSD card is possible.
8. Mode <manual><auto> 9. Quantity 10 10. Smp.time 0.1sek 11. Record <math>R/-</math> 12. Autosave <off><eeprom><sdcard> 13. SD card 14. Exit <math>\leftarrow \rightarrow \uparrow \downarrow ENTER</math></sdcard></eeprom></off></auto></manual>	In order to save file on SD card set <i>Autosave</i> to <i>SDCARD</i> and move cursor to <i>SD card</i> position and press <i>ENTER</i> . The following options will appear:
SD CARD 1. Folder FB_DATA 2. FILE data001.txt 3. Exit	<ul> <li>Folder – enables to inscribe the name of the folder on microSD card,</li> <li><i>FILE</i> – enables to inscribe file name on microSD card,</li> <li><i>EXIT</i> – exit.</li> </ul>
$\leftarrow  \rightarrow  \uparrow  \downarrow  ENTER$	

# 13.3 Configuration

This selection includes all options for setting the gauge's modes of operation.

USER MENU 1.Measurement 2.Memory 3.Configuration 4.Exit	Move the cursor to Configuration and press ENTER.
CONFIGURATION	
<ol> <li>Interface</li> <li>Calibration</li> <li>Info</li> <li>Time&amp;date</li> <li>LCD settings</li> <li>Language</li> <li>Printout</li> <li>Keyboard</li> <li>Auto-OFF</li> <li>Battery</li> <li>External input</li> <li>Firmware Update</li> <li>Defaults</li> <li>Levit</li> </ol>	Move the cursor to the desired option and press <i>ENTER</i> .
ENTER	

## 13.3.1 Setting serial ports

The parameters of the serial connector must be suitable for the device receiving the signal.

-		_
USER MENU		Parameters to be set:
1.Measurement		
2.Memory		- Baudrate – transmission and
3.Configuration		receiving rate (4,800 ÷ 115,200
4.EXI		bps),
		- Bits – number of bits which
CONFIGURATION		constitute a character (7 or 8
1 Interface		bits),
2 Calibration		- Parity – control of parity (no
3.Info		control, even – confirmation of
4.Date/time		parity, or odd – confirmation of
		odd parity),
		- Sending – transmission method
		during measurement:
INTERFACE		- NORMAL – after using the
1. RS-232C		PRINT key, with stable result,
2. USB		- NOSTB – after using the PRINT
3. Exit		key, irrespectively of the result
		stability,
		- <i>AUTOSTB</i> – automatically after
		the result has stabilised,
INTERFACE		- <i>REMOVE</i> – automatically after
1. Baudrate	4800	unload (under 10d or zero
2. Bits	8-bit	signalization threshold)
3. Parity		previous stable result is send; if
5 Exit	NONWAL	PEAK option is on, after
		unloading zeroing of
		indications is carried out,
		- CONTIN. – continuous
INTERFACE		transmission, approx. every 0.1
1. Baudrate	4800	S.
2. Bits	8-bit	
3. Parity	none	
4. Sending <normal><no stb="">&lt;</no></normal>	AUTOSTB> <contin.></contin.>	
J. ⊏XII		

ENTER

 $\rightarrow$ 

←

When the force meter is equipped with two serial interfaces (RS232C and USB) in submenu *Interface* two options are available *RS232C* and *USB*. After choosing proper port all settings are done the same way as above.

### 13.3.2 Force meter calibration

Entrance to calibration is secured by PIN password. Calibration should be executed by AXIS personnel.



Correction option enables changing torque indications with inscribed value.

Factory calibration option enables to return to factory settings.

#### 13.3.3 Information

Option gives basic information about the device.

#### USER MENU

- 1.Measurement 2.Memory
- 3.Configuration
- 4.Exit

#### CONFIGURATION

- 1.Interface 2.Calibration
- 3.Info 4.Date/time
- ...

#### INFO

MODEL MAX SOFT DATE S/N Card AXIS Sp. z o.o. Available information:

- force meter type (Model)
- measurement range (MAX)
- internal software version (SOFT)
- serial number (S/N)
- production date (DATE)
- memory card type (Card)
- producer name

#### 13.3.4 Setting date and time

This option is used for entering the current date and time. Access to this setting is secured by the PIN code.

- 1.Measurement
- 2.Memory
- 3.Configuration
- 4.Exit

#### CONFIGURATION

- 1.Interface
- 2.Calibration
- 3.Info
- 4.Date/time
- •••

TIME&DAT	E
1. Time 2. Date 3. PIN	10:00:00 2011-01-11 0 <yyyy-mm-dd><mm-dd-< td=""></mm-dd-<></yyyy-mm-dd>
5. Exit	YYYY> <dd-mm-yyyy></dd-mm-yyyy>
	↑ ↓ ENTER

Use the navigation keys and *ENTER* to select *Date and time*. If a *PIN* has already been entered (other than 0), after selecting *Time* or *Date*, the cursor will move to the *PIN* option, where a correct 4-digit *PIN* has to be entered. To enter the correct digits, use the  $\uparrow, \downarrow, \rightarrow, \leftarrow$  keys and *ENTER*.

To enter a new code (*NEW*), select the *PIN* option. When entering a new code, type in the same number twice (message: *REP*.).

The *FORMAT* option allows for the selection of the date format on print-outs.

#### 13.3.5 LCD settings

This option adjusts the gauge's display to external lighting conditions.



#### 13.3.6 Selecting the menu language

Three menu languages are available: <PL> – Polish, <ENG> – English, <DE> – German, <ESP> - Spanish.

#### USER MENU

1.Measurement 2.Memory 3.Configuration 4.Exit

#### CONFIGURATION

- ...
- 4. RS-232C settings
- 5. LCD settings
- 6. Language
- 7. Date and time
- 8. Auto-OFF

#### LANGUAGE

- 1. Language
- 2. Exit

←	$\rightarrow$	ENTER

<PL><ENG><DE><ESP>

Use the navigation keys and *ENTER* to select *Language*. To select one of the available menu languages, use the  $\rightarrow$ ,  $\leftarrow$  keys and *ENTER*.

To enter a new code (*NEW*), select the *PIN* option. When entering a new code, type in the same number twice (message: *REP*.).

#### 13.3.7 Printout settings

According to the requirements of GLP procedures, it is possible to use an external printer to produce print-outs from the gauge including text information.

USER MENU 1.Measurement 2.Memory 3.Configuration 4.Exit
CONFIGURATION
<ul><li>5. LCD settings</li><li>6. Language</li><li>7. Printout</li><li>4 Interface</li></ul>
PRINTOUT
<ul> <li>☐ Heading</li> <li>☐ Date</li> <li>☐ Time</li> <li>☐ ID1&gt;</li> <li>☐ ID2&gt;</li> <li>☐ ID3&gt;</li> <li>☐ Number</li> </ul>
ENTER →
PRINTOUT
<ul> <li>Heading</li> <li>Date</li> <li>Time</li> <li>ABCD</li> <li>ID2</li> <li>ID3</li> </ul>
$\uparrow \qquad \downarrow \qquad \downarrow \qquad \uparrow \qquad \text{ENTER}$

Use the navigation keys and *ENTER* to select *Printout* and the suitable print components.

*ID1, ID2, ID2* – text strings (up to 20 characters) forming the lines of the print-out, entered using the gauge's navigation keys (starting from  $\rightarrow$ ).

To enter the characters, select ID using ENTER and press  $\rightarrow$ . The characters are entered using the navigation keys  $\uparrow$  and  $\downarrow$ . To move the cursor to the consecutive positions, use  $\leftarrow$  and  $\rightarrow$ . To confirm the entered string, ENTER. press То delete а character, enter space

#### 13.3.8 Turning the sound ON/OFF when using the keypad (beep)

This options turns ON or OFF the sound signalling that a key on the keypad has been pressed. When the sound is turned on, the user usually does not apply excessive force when pushing the keys.

USER MENU	
1.Measurement 2.Memory 3.Configuration 4.Exit	
	CONFIGURATION
<ol> <li>Printout</li> <li>Interface</li> <li>LCD settings</li> <li>Language</li> <li>Time&amp;date</li> <li>Keyboard</li> </ol>	
KEYBOARD	
1. BEEP 2. Exit	<on><off></off></on>
	↑ ↓ ENTER
KEYBOARD	
1. BEEP 2. Exit	<on></on>
	$\leftarrow  \rightarrow  ENTER$

Use the navigation keys and *ENTER* to select *Keypad* and *Buzzer*, and one of the following options:

- ON sound ON,
- OFF sound OFF.

#### 13.3.9 Automatic power OFF (Auto-OFF)

This option allows for an automatic cut-off of the gauge's power supply to save the battery's energy.

USER MENU

- 1.Measurement
- 2.Memory
- 3.Configuration
- 4.Exit

CONF	FIGURATION
1.Interface 2.Calibration 3.Info 4.Time&date 5.LCD settings 6.Language 7.Printout 8.Keyboard 9.Auto-OFF 10.Battery 11.External input 12.Firmware Update 13.Defaults 14 Evit	
AUTO-OFF	
1. <mark>Status</mark> 2. Exit	OFF
	↑ ↓ ENTER
AUTO-OFF	
1. <mark>Status</mark> : 2. Exit	<off>   Bat&gt; <on></on></off>
L	← → ENTER

Use the navigation keys and *ENTER* to select *Auto-OFF* and *Status,* and one of the following options:

-ON – the power is turned off after 5 minutes, the indications remain unchanged,

-BAT – the power is turned off when the battery is low,

- OFF – the power is not turned off.

## 13.3.10 Monitoring the batteries' charge level (Battery)

This option is used for reading the charge level of the batteries and allows for the charging to be turned off to protect ordinary batteries, if such batteries are used instead of rechargeable batteries.



Charging ordinary batteries used instead of rechargeable batteries may lead to major damage to the gauge.



Use the navigation keys and *ENTER* to select *Battery* and *Charging*, and one of the following options:

- ON charging ON,
- OFF charging OFF.

## 13.3.11 External input

This option can be used when force gauge is applied in any kind of automated process. THRESHOLD (optionally) output is used for this function so when using this option threshold function should be turned off.

USER MENU	Using navigation keys and <i>ENTER</i>
1.Measurement	key choose <i>Configuration</i> option
2.Memory	and then <i>External input</i> . Choose
3.Configuration	<i>Status</i> option and using $\leftarrow$ and $\rightarrow$
4.Exit	keys choose from:
CONFIGURATION  8. Keyboard 9. Auto-OFF 10. Battery 11. External input EXTERNAL INPUT 1. Status : <off><trigger><gate> 2. Exit</gate></trigger></off>	<ul> <li><i>OFF</i> – function off,</li> <li><i>TRIGGER:</i> <ul> <li>a) manual measurement mode –</li> <li>measurement storing initiated by a single external signal,</li> <li>b) automatic measurement mode –</li> <li>storing of set quantity of</li> <li>measurements initiated by a single external signal,</li> <li><i>GATE:</i></li> <li>a) manual measurement mode -</li> <li>measurement storing initiated by a single external signal while <i>MEM</i></li> <li>key is pressed,</li> <li>b) automatic measurement mode –</li> <li>storing of set quantity of</li> </ul></li></ul>

## 13.3.12 Firmware update

Option designated for service

Option enables program update by connecting force gauge to computer using RS232 or USB interface. *Firmware update* message on force gauge's display is connected with this option. To delete this message, disconnect the force gauge from supply.

### 13.3.13 Defaults

This option restores factory settings (default settings) for all options.

USER MENU
1.Measurement 2.Memory 3.Configuration 4.Exit
CONFIGURATION
7. Date and time 8. Auto-OFF 9. Battery 10. Defaults
DEFAULTS
Restore default settings?
NO YES
$\uparrow$ $\downarrow$ ENTER

Use the navigation keys and *ENTER* to select *Reset settings* and the option *YES*.

As a result of restoring factory settings, the gauge will reset and start continuous measurement.

## 14. Maintenance, troubleshooting and repairing minor types of damage

- 1. Keep the gauge clean.
- 2. When using the force gauge, make sure that no contamination gets between the gauge plunger and the enclosure. Upon identifying any contamination, remove it using a tool which does not conduct electricity.
- 3. Unauthorised person may not perform any repairs.
- 4. Have the gauge repaired by your local servicing facility. A list of servicing facilities is enclosed in the warranty.

#### Messages and faults:

Message/fault	Cause	Recommendation
The message RESETTING is	Resetting process	Keep the gauge in motionless position
displayed for an extended	disturbed	and press $\rightarrow T(0) \leftarrow$
period of time.		
Message:	Resetting process	Put the gauge in horizontal position and
	disturbed	turn it off and on using the ON/OFF key.
AD range exceeded (+/-)		
The values indicated by the	Gauge out of	Contact a servicing facility to calibrate
gauge diverge significantly	adjustment	the gauge
from correct values		
Units displayed are different	UNIT/CLEAR key	Press the UNIT/CLEAR key several times
from the selected units	pressed by accident	to display the correct units



## 15. FSB menu diagram



